

Leather Protector Gloves LPG 10

The NOVAX[®] Leather Protector Gloves provides an extra layer of safety for rubber insulating gloves. They are to be used only for mechanical protection against abrasions, cuts, tears and punctures for the insulating gloves. The Leather Protectors should always be worn over the Rubber Insulating Gloves when live working.

Standard	EN 420, EN 388
Rating	2121X
Material	Leather
Leather Type	Goatskin grain
Colour	Grey
Thickness	0.80mm (Palm, Back & Cuff)
Size	7 – 12
Length	254mm (10")
Draw Strap	Shirred elastic
Weight (g) / pair	Approx. 144 – 168 (<i>depending on size</i>)
Packing	1 pair in a polybag, 25 polybags in an export carton



Recommended use:

- With NOVAX[®] Class 00 – 0 rubber insulating gloves.

Sizes	7	8	9	10	11	12
Palm Circumference Measurement	250mm	260mm	270mm	280mm	290mm	300mm

Which Glove Size Is Right For Me?

NOVAX[®] leather protector gloves are unique where it will fit the same size of NOVAX[®] rubber insulating used.
Example: If a Class 0, Size 10 rubber insulating gloves is being used, the right leather protector to be used is Size 10.

Warning: The leather protectors are to be used only for mechanical protection for the rubber insulating gloves and shall not be used for electrical protection.

Any enquiries, please reach out to us at sales@novax-intl.com or visit our website at www.novax-intl.com