

Leather Protector Gloves LPG 12

The NOVAX[®] Leather Protector Gloves provides an extra layer of safety for rubber insulating gloves. They are to be used only for mechanical protection against abrasions, cuts, tears and punctures for the insulating gloves. The Leather Protectors should always be worn over the Rubber Insulating Gloves when live working.

Standard	EN 420, EN 388
Rating	2121X
Material	Leather and Nylon
Leather Type	Goatskin grain on back and palm Cow split leather on cuff
Colour	Grey
Thickness	0.80mm (Palm & Back) 1.20mm (Cuff)
Size	7 – 12
Length	305mm (12")
Draw Strap	Adjustable strap
Weight (g) / pair	Approx. 200 – 261 (<i>depending on size</i>)
Packing	1 pair in a polybag, 25 polybags in an export carton



Sizes	7	8	9	10	11	12
Palm Circumference Measurement	250mm	260mm	270mm	280mm	290mm	300mm

Recommended use:

- With NOVAX[®] Class 1 – 2 rubber insulating gloves.

Which Glove Size Is Right For Me?

NOVAX[®] leather protector gloves are unique where it will fit the same size of NOVAX[®] rubber insulating used.

Example: If a Class 2, Size 10 rubber insulating gloves is being used, the right leather protector to be used is Size 10.

Warning: The leather protectors are to be used only for mechanical protection for the rubber insulating gloves and shall not be used for electrical protection.

Any enquiries, please reach out to us at sales@novax-intl.com or visit our website at www.novax-intl.com